

COMPRESSOR / CONDENSER TROUBLESHOOTING

POSSIBLE CAUSES

| | | | | | | | | | | | | | ru | 991B | LE | AU | OEO | | | | | | | | | | | | |
|--|---------------|-------------|---------------|-----------------------|----------------------|----------------------------|----------------------|-----------------------|---------------------|---------------------|--------------------------|-------------------------|----------------------|-------------------------|-------------|--------------|--------------|-----------------------|----------------------|-----------------------|-------------|---------------------------|--------------------------------|------------------------------------|--------------------------------|-----------|-------------------|-------------------------------|-----------------------------|
| SYMPTOM / COMPLAINT | Power Failure | Low Voltage | Blown Breaker | Disconnect Switch Off | Loose or Broken Wire | Incorrectly Set Thermostat | Defective Thermostat | Defective Transformer | Compressor Grounded | Defective Contactor | Bad Compressor Capacitor | Bad Fan Motor Capacitor | Defective Compressor | Bad Condenser Fan Motor | Restriction | Undercharged | Dirty Filter | Dirty Evaporator Coil | Dirty Condenser Coil | Insufficient Air Flow | Overcharged | Noncondensables in System | Defective Evaporator Fan Motor | Bad Evaporator Fan Motor Capacitor | Thermostat Incorrectly Located | Duct Work | System Undersized | Condenser Incorrectly Located | Blower Wheel Loose on Shaft |
| No Cooling Compressor and fan are running | X | Х | х | X | X | X | X | | | | | | | | | | | | | | | | | | | | | | |
| Insufficient Cooling Compressor and fan are running | | | | | | X | X | | | | | | | | X | X | X | X | X | X | X | X | | | X | X | X | X | X |
| Compressor Will Not Start Indoor fan runs | | X | X | | X | X | X | X | X | X | X | | X | | | X | | | | | | | | | | | | | |
| Insufficient Air Flow | | | | | | | | | | | | | | | | | X | X | | | | | X | | | X | X | | X |
| Outdoor Fan Will Not Start Compressor runs | | | | | X | | | | | | | X | | X | | | | | | | | | | | | | | | |
| Indoor Fan Will Not Start Compressor runs | | | | | X | | | | | | | | | | | | | | | | | | Х | Х | | | | | |
| Compressor Short Cycles Outdoor fan runs | | Х | | | X | | X | | | X | Х | | X | | | | Х | Х | Х | | | X | | | X | | | | |
| Compressor Runs Continuously | | | | | | X | X | | | X | | | Х | | X | Х | Х | Х | Х | | | X | | | X | Х | X | X | X |
| Breaker Tripping | | X | | | X | | | | X | X | X | X | X | X | | | X | X | X | | | | X | X | | | | | |
| Noisy Unit / Excessive Air Noise | | | | | | | | | | X | | | X | | | | | | | | | | | | | X | | | X |
| Fan(s) Run Intermittently Compressor running | | | | | X | X | X | | | | | X | | X | | | | | | | | | X | X | | | | | |
| Evaporator Icing Up | | | | | | | | | | | | | | | X | X | X | X | | X | | X | X | X | X | X | X | X | X |
| Sweating Ducts | | | | | | | | | | | | | | | | | | | | | | | | | | X | | | |
| Noisy Compressor | | | | | | | | | | | | | X | | | | | | | | X | | | | | | | | |
| High Head Pressure | | | | | | | | | | | | | X | X | | | X | X | X | X | Х | X | X | X | | | | X | X |
| Low Head Pressure | | | | | | | | | | | | | Х | | | X | | | | | | | | | | | | | |
| High Suction Pressure | | | | | | | | | | | | | Х | | | | | | | | X | | | | | | | | |
| Low Suction Pressure | | | | | | | | | | | | | | | X | X | X | X | X | X | | | | | | | | | |
| Insufficient Cooling | | | | | | X | X | | | | | | X | X | X | X | X | X | X | X | | X | X | | X | X | X | X | X |

CHV024 - 10-19-11

Some items on this page may require additional delivery time. For more information please call 1-800-431-3000.