



3 in 1 Wireless Charging Stand

User's Guide for Model IACQ491B v2747-01



Features

- Wireless standard inductive charging
- Compatible with wireless Fast Charge devices
- Over current, over voltage, high temperature and short circuit protection
- Input voltage/current: 9V 2A / 5V 3A / 12V 1.5A
- Output power: 10W - 7.5W - 5W




Place wireless charging enabled device on the Power Pad to begin charging. Place earbud case on to the lightning charging connector.

Includes

- Fast Charge USB-C power cable
- QC 3.0 power adapter
- User manual

Connecting Power Supply

To power the unit, plug the USB-C fast charging cable (included) into the DC Power Input on the back of the charging stand and the other end into the provided QC 3.0 USB power adapter (included) and standard power outlet.



Fast Charging

Note : Use only included charging equipment. Unauthorized chargers may cause damage or the wireless charger may malfunction.

Fast charging is only compatible with supported devices and the included USB Power Cable.

On supported devices, if the "fast/rapid charging" feature is not selected, you may need to enable it from your device's Settings, Power, or Battery menu. Consult the user's manual for your specific device for more information.

Foreign Object Detection (FOD)

When the Charger detects a metallic or magnetic object on the pad that will interfere with the normal operation of the charger, the **Indicator Light** will flash both green and blue and wireless charging will automatically stop.

Notes On Wireless Charging

Do not block the cooling vents on the rear of the pad. There is a risk of overheating which may cause injury or damage.

Do not leave the charger and your mobile device unattended while charging.

Depending on the location of the charging coil on your mobile device, your device may not charge in all positions. Find the position that works best for your device.

If you are using your device with a connected headset, place the device in the landscape position. Placing your device in the portrait position may move its charging coil out of position to charge.

Wireless charging may not work if you have a case that is A) too thick or B) has a magnet. In order to charge, you will need to remove the case before placing on the charging pad.

If you are using an attached wireless charging case on your mobile device, never place just the case on the charging pad. This may overheat the charging pad and/or the case, and has a risk of fire and injury.

If you connect a wired or portable battery charger to your device while it is on the charging pad, the pad will disable wireless charging.

The wireless charger does not have a power switch. To save energy, unplug the wireless charger from its power source.

The wireless charger may cause interference in areas with weak Wi-Fi signal.

Before using, be sure to remove the protective film that covers the charger base where your phone rests.

Customer Support

Customer Service: 1-888-999-4215 | **Email Support:** prodinfo@dpiinc.com | **Email Parts:** partsinfo@dpiinc.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iLiveElectronics.com

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.iLiveElectronics.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iLiveElectronics.com



Copyright © 2020 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.

Safety Warnings.

- **WARNING:** To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- **WARNING :** Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.
- Do not place foreign materials, such as metal objects, magnets, or the like, between a mobile device and the charging surface. This may interrupt charging and may cause damage from overheating.
- Only use with the included power supply.



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. **This product meets and complies with required Federal product guidelines.**